


DNV  
Quality Assured  
ISO9001

JAS-ANZ

REV No	Desc	BY	DATE
6	UPDATED TO SUIT QUICKFIT ADAPTOR	RS	12/08/13



TOLERANCES (mm)	
X	± 0.5
X.X	± 0.1
X.XXX	± 0.025
UNLESS OTHERWISE SPECIFIED	
MATERIAL	
FINISH	

**MUIR** WINDLASSES AUSTRALIA

TITLE  
VR/VRC/VFF 600  
DECK TEMPLATE

PART No.

DRN	DATE	DRG No
JK	25/7/2000	600A-DTEMP
SCALE	APP1	APP2
1:1		

SIZE  
A4

© COPYRIGHT MUIR ENGINEERING PTY. LTD.

**IMPORTANT: VERIFY SCALE BEFORE USING AS TEMPLATE**



Ø20 HOLE FOR AUTO ANCHOR SENSOR (WHERE FITTED)

CUT OUT Ø63.5

4 HOLES Ø12 ON PCD 87

8

38

CHAIN CENTRE LINE

BOW

A

A

CUT OUT FOR ROPE/CHAIN (MAKE THIS EXACT SHAPE TO PREVENT SNAGGING)

CUT HOLE FOR CHAIN EXACTLY AS SHOWN ON TEMPLATE WITH BELLED OUT BOTTOM

SECTION A-A OF DECK

